















Angle guide



Angle guide can be raised and lowered with rack and pinion mechanism, allowing fine vertical adjustment.

Angle adjustable fence



Angle adjustable fence can be locked in any position between 0° and 90° with positive stops at 0°, 45° and 90°.

Depth adjusting knob




Cutting depth can be preset in 6 stages by simply rotating the depth adjusting knob (stopper).

Easy blade replacement



Blade cover can be opened just by loosening clamp screw.





*Weight according to EPTA-Procedure 01/2003

Items of standard equipment and specifications may vary by country or area.

